

MP CONCEPTS

15-17 GT350 Style Rocker Winglets



Wash the fender and rocker pannel with soap and water. Allow the panel to dry. ****Recommended:** Wipe the panel down with isopropyl alcohol to ensure the cleanest surface possible.



Apply the supplied 3M tape. Test fit the part on the rocker to familiarize yourself with how the part should fit.



Remove the 3M tape backing, install the winglet onto the fender. Apply firm even pressure to ensure proper adhesion.